Preparation

Part Numbers: PT924-48140-##

Kit Contents

Item#	Quantity Reqd.	Description
1	1	Cargo Tray
2	10	Adapter Pads
3		

Hardware Bag Contents

Item #	Quantity Reqd.	Description
1		
2		
3		

Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		
2		
3		

Conflicts

None

Recommended Tools

Personal & Vehicle	Notes	
Protection		
Cover or blanket		
Special Tools	Notes	
None		
Installation Tools	Notes	
None		
Special Chemicals	Notes	
None		

General Applicability

MY19 and newer Highlander, Highlander HV models

Recommended Sequence of Application

recommended sequence of application		
	Item#	Accessory
	1	
	2	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item#	Quantity Reqd.	Description
1		
2		
3		

Legend



STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.



OPERATOR SAFETY: Use caution to avoid risk of injury.



<u>CAUTION:</u> A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.



TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.



<u>REVISION MARK:</u> This mark highlights a change in installation with respect to previous issue.



SAFETY TORQUE: This mark indicates that torque is related to safety.

Issue: C 02/04/2020

Procedure


Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.


These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.






1. Prepare the Vehicle

- (a) Open package and check part for damage and kit contents, including 10 adapter pads attached to velcro on the seatback area of liner (Fig 1-1).
- (b) Open the rear door.
- (c) Remove any cargo and debris from the rear cargo area.
- (d) Place vehicle protection over the rear bumper.

2. Install the Cargo Tray

- (a) Place the cargo tray in the trunk area with the logo towards the rear of the vehicle and facing up (Fig. 2-1).
- (b) Pull rear seat straps through cut-outs in tray.
- (c) Ensure tray makes full contact with trunk floor.



(d) Rub/massage areas of cargo tray shown to ensure proper velcro attachment to seatback before actuating rear seats up (Fig. 2-2).

CARGO TRAY

- (e) When actuating seats up for the first few times, push hinge area down until seat is half upright. This will condition the liner to fall in place on the vehicle.
- (f) Due to shipping method, it may take up to 24 hours of warmth (room temperature) to completely form to its intended shape and lie flat.

3. Complete the Installation

- (a) Remove the vehicle protection.
- (b) Close the rear door.

TOYOTA HIGHLANDER/HV 2014 - 2019

CARGO TRAY

Checklist - these points **MUST** be checked to ensure a quality installation. Check: Look For: **Accessory Function Checks** Correct part number has been installed Verify part number on package. **Vehicle Function Checks** Vehicle Appearance Check After accessory installation and removal of Ensure no damage (including scuffs and scratches) protective cover(s), perform a visual was caused during the installation process. inspection. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)